OS-NET Engineering Test Guide

OS-NET enabled luminaires: as many as available.

OS-NET Sensors and general luminaires: as many as available.



FOREWORD

This document is prepared for the persons who intend to conduct engineering test on the OS-NET devices at lab. Before start testing, please have the following devices ready;

	OS-NET Button/Power Pack: if required.OS-NET Remote: one is enough.			
Procedure and Instructions			Reminders	
1.	Connecting the Devices		Ensure that all devices are correctly	
1.1	Have the OS-NET enabled luminaires (if available) ready for test, or		connected.	
	connect the OS-NET Sensors/Power Packs to the controlled light		Separate the devices to avoid cross-	
	respectively.		programming.	
1.2	Connect Hot (Live) and Neutral wires to OS-NET Button (if available).		Suggest covering the sensors to avoid	
1.3	Apply mains power, each ONS will turn on the connected light and its LED		unwanted detection.	
	will blink "twice" in BLUE to indicate sensor operation.			
2.	Creating the Network		The connected lights will be on and	
2.1	Activate the remote (with rubber cover on) and enter into the EZ-GROUP		off two times to acknowledge the	
	setting page as per next page.		setting commands received.	
2.2	Assign the 1st OS-NET Sensor to a group (ex. 001). The LED indicator will		The target sensor will respond with a	
	blink from BLUE to GREEN and continue for a period of time.		few short beeps and a long beep	
2.3	Assign the 2nd OS-NET Sensor to the same group (ex. 001) within 1		after 5 seconds.	
	minute. The LED's of two sensors shall blink in BLUE and GREEN		Ensure to group only ONE sensor at a	
	intermittently. If both sensors eventually blink in GREEN, it means that an		time. Cover the other sensors to	
	OS-NET network is successfully created.		avoid grouping failure.	
3.	Grouping Other Devices		There will be no more 1-minute time	
3.1	Continue to assign other OS-NET devices to the same or different groups		limit for grouping the other devices.	
	as testing required. The LED of grouping device will blink in BLUE and		Ensure to group only ONE device at a	
	GREEN intermittently while linking to the network, and eventually blink in		time.	
	GREEN to indicate successful network linkage.			
4.	Setting the Control Scheme		The connected lights will be switched	
4.1	Enter into the DEVICE setting pages from SETTING MENU.		on and off two times to acknowledge	
4.2	To set all sensors of the group with the same control scheme and		receiving the setting commands.	
	parameters, select the "GROUP-SET".		Sensors of the same group can be set	

NOTE

- 1. If all devices are placed on the test bench together, ensure to separate or block the non-target devices to avoid receiving the unwanted IR commands that will result in programming failure.
- 2. Strong light nearby the sensor may affect the IR communication.

4.3 To set an individual device with specific control scheme and parameters of,

- 3. <u>Lock the network after configuration</u> to prevent accidental linkage by neighboring network. A locked network will allow only certain remote control operations, including Light ON, Light OFF, Manual dimming, TEST, BURN-IN, current lux/dim and network data reading. Unlock the network to conduct other operations.
- 4. For detailed remote operation and programming, please refer to the OS-NET Programming Guide available from www.irtec.com

select the "INDIV-SET".

to control the connected lights in

different scheme.





EZ-GROUP Setting Procedure

Step	Remote Display	Remote Operation and Notes
1	ON UPLOAD OFF DOWNLOAD Q	Press any key to enter the MAIN MENU. Press to enter the SETTING menu.
2	SETTING GROUP LINK DEVICE FIND DEVICE LOCK/UNLOCK BACK ENTER	Select GROUP LINK. Press to enter the GROUP LINK page.
3	GROUP LINK EZ-GROUP ADVANCED UNGROUP BACK ENTER	Select EZ-GROUP. Press to enter the EZ-GROUP page.
4	EZ-GROUP MBROFGRP 001 MBROFGRP MBROFGRP	Select the group number (001-250) to be assigned for the device on the 1st MBR OF GRP. Press to upload the grouping data. NOTE: 001 is just an example.
5	AIM & HOLD + PRESS - BACK ENTER	Aim the remote at the target sensor or closed to the button. Press and hold until transmission completed. NOTE: The OS-NET Sensor will respond with a few short beeps, and a long beep after about 5 seconds.
6	UPLOAD OK BACK AGAIN	To assign the other sensor to the SAME group, aim the remote at the sensor and press — to upload again. To assign the other devices to a DIFFERENT group, go back to Step 4, select a new group number and repeat Step 5.