

FOREWORD

This document is prepared for the persons who intend to conduct engineering test on the OS-NET devices at lab. Before start testing, please have the following devices ready;

- OS-NET enabled luminaires: as many as available.
- OS-NET Sensors and general luminaires: as many as available.
- OS-NET Button/Power Pack: if required.
- OS-NET Remote: one is enough.

Procedure and Instructions		Re	Reminders	
1.	Connecting the Devices		Ensure that all devices are correctly	
1.1	Have the OS-NET enabled luminaires (if available) ready for test, or		connected.	
	connect the OS-NET Sensors/Power Packs to the controlled light		Separate the devices to avoid cross-	
	respectively.		programming.	
1.2	Connect Hot (Live) and Neutral wires to OS-NET Button (if available).		Suggest covering the sensors to	
1.3	Apply mains power, each ONS will turn on the connected light and		avoid unwanted detection.	
	its LED will blink "twice" in BLUE to indicate sensor operation.			
2.	Creating the Network		The connected lights will be on and	
2.1	Activate the remote (with rubber cover on) and enter into the EZ-		off two times to acknowledge the	
	GROUP setting page as per next page.		setting commands received.	
2.2	Assign the 1st OS-NET Sensor to a group (ex. 001). The LED indicator		The target sensor will respond with	
	will blink from BLUE to GREEN and continue for a period of time.		a few short beeps and a long beep	
2.3	Assign the 2nd OS-NET Sensor to the same group (ex. 001) within 1		after 5 seconds.	
	minute. The LED's of two sensors shall blink in BLUE and GREEN		Ensure to group only ONE sensor at	
	intermittently. If both sensors eventually blink in GREEN, it means		a time. Cover the other sensors to	
	that an OS-NET network is successfully created.		avoid grouping failure.	
3.	Grouping Other Devices		There will be no more 1-minute	
3.1	Continue to assign other OS-NET devices to the same or different		time limit for grouping the other	
	groups as testing required. The LED of grouping device will blink in		devices.	
	BLUE and GREEN intermittently while linking to the network, and		Ensure to group only ONE device at	
	eventually blink in GREEN to indicate successful network linkage.		a time.	
4.	Setting the Control Scheme		The connected lights will be	
4.1	Enter into the DEVICE setting pages from SETTING MENU.		switched on and off two times to	
4.2	To set all sensors of the group with the same control scheme and		acknowledge receiving the setting	
	parameters, select the "GROUP-SET".		commands.	
4.3	To set an individual device with specific control scheme and		Sensors of the same group can be	
	parameters of, select the "INDIV-SET".		set to control the connected lights	
			in different scheme.	

NOTE

- 1. If all devices are placed on the test bench together, ensure to separate or block the non-target devices to avoid receiving the unwanted IR commands that will result in programming failure.
- 2. Strong light nearby the sensor may affect the IR communication.
- 3. <u>Lock the network after configuration</u> to prevent accidental linkage by neighboring network. A locked network will allow only certain remote control operations, including Light ON, Light OFF, Manual dimming, TEST, BURN-IN, current lux/dim and network data reading. Unlock the network to conduct other operations.
- 4. For detailed remote operation and programming, please refer to the OS-NET Programming Guide available from <u>www.irtec.com</u>



EZ-GROUP Setting Procedure

Step	Remote Display	Remote Operation and Notes
1	ON UPLOAD OFF	Press any key to enter the MAIN MENU. Press 🖵 to enter the SETTING menu.
2	SETTING GROUP LINK DEVICE FIND DEVICE LOCK/UN LOCK BACK ENTER	Select GROUP LINK. Press • Ito enter the GROUP LINK page.
3	GROUP LINK EZ-GROUP ADVANCED UNGROUP	Select EZ-GROUP. Press 🖵 to enter the EZ-GROUP page.
4	EZ-GROUP MEROFCRP 0 001 MBR OF GRP MBR OF GRP MBR OF GRP BACK UPLOAD	Select the group number (001-250) to be assigned for the device on the 1st MBR OF GRP. Press Io upload the grouping data. NOTE: 001 is just an example.
5	AIM & HOLD + PRESS + BACK ENTER +	Aim the remote at the target sensor or closed to the button. Press and hold until transmission completed. NOTE: The OS-NET Sensor will respond with a few short beeps, and a long beep after about 5 seconds.
6		To assign the other sensor to the SAME group, aim the remote at the sensor and press