## OS-NET EZ-GROUP Guide

Every OS-NET device must be assigned to a group to link up the network. EZ-GROUP setting allows you to quickly group and link the OS-NET devices to the network. Most group controls can be achieved by conducting the EZ-GROUP setting operations as below.

## 1. Single-Group Control Devices



## 2. Multi-Group Control Devices

Multi-group control means that a grouped OS-NET Sensor/Button/Power Pack can activate/control multiple lighting groups. An OS-NET device can be a member of up to 4 groups.

Step	Remote Display	Remote Operation and Notes
1	ON UPLOAD OFF	Press any key to enter the MAIN MENU. Press 🖵 to enter the SETTING menu.
2	SETTING GROUP LINK DEVICE FIND DEVICE LOCK/UNLOCK BACK ENTER	Select GROUP LINK. Press  • Ito enter the GROUP LINK page.
3	GROUP LINK EZ-GROUP ADVANCED UNGROUP	Select EZ-GROUP. Press 🖵 to enter the EZ-GROUP page.
4	EZ-GROUP MBROFGRP @ 0 1 1 MBR OF GRP @ 0 1 2 MBR OF GRP @ 0 1 3 MBR OF GRP @ MBR OF MAR OF GRP @ MBR OF MAR OF MAR OF MAR OF MAR OF MAR	Select the group numbers (001-250) for the target device on the lines of MBR OF GRP. Select 2/3/4 numbers for 2/3/4 control groups respectively. Press $\checkmark$ to upload the grouping data. NOTE: Group 011, 012 and 013 are just examples.
5	AIM & HOLD + PRESS + BACK ENTER +	Aim the remote at the target device. Press and hold until transmission completed. NOTE: The OS-NET device will respond according to the setting acknowledgement indication chart on the installation instructions.
6		To assign the other devices to the SAME groups, aim the remote at the device and press $\checkmark$ to upload again. To assign the other devices to DIFFERENT groups, go back to Step 4, select the new group numbers and repeat Step 5.